

Loading the Washing Machine

MATERIALS NEEDED



Items



Washing Machine



Dirty Laundry



Laundry Detergent

Environment



Laundry room

Loading the Washing Machine



DIRECTIONS

1	Locate laundry	8	Locate detergent
2	Take laundry to the washing machine	9	Open detergent
3	Open washing machine door	10	Slowly pour detergent in dispenser for 2-3 seconds
4	Put laundry in washing machine	11	Close detergent dispenser
5	Close washing machine door	12	Close and return detergent
6	Locate detergent dispenser	13	Locate and press the correct cycle
7	Open detergent dispenser	14	Locate, press and hold start